

Using Orton Pyrometric Cones

Cone Numbers 022-14



Pyrometric cones have been used to monitor ceramic firings for more than 100 years. They are useful in determining when a firing is complete, if the kiln provided enough heat, if there was a temperature difference in the kiln or if a problem occurred during the firing.

These tables provide a guide for the selection of cones. The actual bending temperature depends on firing conditions. Once the appropriate cones are selected, excellent, reproducible results can be expected.

Temperature Equivalents for Orton Pyrometric Cones (°F)

Cone #	Self Supporting Cones			Large Cones			Small					
	Regular – SSB		Iron Free – SSK	Regular – LRB		Iron Free – IFB	Regular					
	Heating Rate*	Firing Speed	Slow	Medium	Fast	Slow	Medium	Fast				
022	27°F/hr	108°F/hr	270°F/hr	27°F/hr	108°F/hr	270°F/hr	108°F/hr	270°F/hr	540°F/hr			
021												
020												
019												
018												
017												
016	1368	1422	1465		1416	1461		1517				
015	1382	1456	1504		1450	1501		1549				
014	1395	1485	1540		1485	1537		1598				
013	1485	1539	1582		1539	1578		1616				
012	1549	1582	1620		1576	1616		1652				
011	1575	1607	1641		1603	1638		1679				
010	1636	1657	1679	1600	1627	1639	1648	1675	1623	1636	1686	
09	1665	1688	1706	1650	1686	1702	1683	1702	1683	1699	1751	
08	1692	1728	1753	1695	1735	1755	1728	1749	1733	1751	1801	
07	1764	1789	1809	1747	1780	1800	1783	1805	1778	1796	1846	
06	1798	1828	1855	1776	1816	1828	1823	1852	1816	1825	1873	
05½	1839	1859	1877	1814	1854	1870	1854	1873	1852	1868	1909	
05	1870	1888	1911	1855	1899	1915	1886	1915	1890	1911	1944	
04	1915	1945	1971	1909	1942	1956	1940	1958	1940	1953	2008	
03	1960	1987	2019	1951	1990	1999	1987	2014	1989	1996	2068	
02	1972	2016	2052	1983	2021	2039	2014	2048	2016	2035	2098	
01	1999	2046	2080	2014	2053	2073	2043	2079	2052	2070	2152	
1	2028	2079	2109	2046	2082	2098	2077	2109	2079	2095	2163	
2	2034	2088	2127				2088	2124			2174	
3	2039	2106	2138	2066	2109	2124	2106	2134	2104	2120	2185	
4	2086	2124	2161				2120	2158			2208	
5	2118	2167	2205				2163	2201			2230	
5½	2133	2197	2237									
6	2165	2232	2269				2228	2266			2291	
7	2194	2262	2295				2259	2291			2307	
8	2212	2280	2320				2277	2316			2372	
9	2235	2300	2336				2295	2332			2403	
10	2284	2345	2381				2340	2377			2426	
11	2322	2361	2399				2359	2394			2437	
12	2345	2383	2419				2379	2415			2471	
13	2389	2428	2458				2410†	2455†				
14	2464	2489	2523				2530†	2491†				

Cones made with red iron oxide
Cones made without iron oxide

* Heating Rate during the last 180°F / 100°C of Firing

** Fired in a gas kiln

Temperature Equivalents for Orton Pyrometric Cones (°C)

Cone #	Self Supporting Cones			Large Cones			Small		
	Regular – SSB		Iron Free – SSK	Regular – LRB		Iron Free – IFB	Regular		
	Heating Rate*	Firing Speed	Slow	Medium	Fast	Slow	Medium	Fast	
022	15°C/hr	60°C/hr	150°C/hr	15°C/hr	60°C/hr	150°C/hr	60°C/hr	150°C/hr	300°C/hr
021									
020									
019									
018									
017									
016									
015									
014									
013									
012									
011									
010									
09									
08									
07									
06									
05½									
05									
04									
03									
02									
01									
1									
2									
3									
4									
5									
5½									
6									
7									
8									
9									
10									
11									
12									
13									
14									

Temperatures shown are for specific mounted height above base. For Self Supporting - 1 ¾"; for Large - 2"; for Small - 15/16". For Large Cones mounted at 1 ¾" height, use Self Supporting temperatures. † These Large Cones have different compositions and different temperature equivalents.

Behavior of Pyrometric Cones

Pyrometric cones deform due to the formation of glass and the pull of gravity as they are heated to their designed operating temperature. This is known as pyro plastic deformation. Careful control over the shape and composition allows Orton to provide a standardized product that reliably performs to known heating conditions. Cones bend and deform in an arc as they start to develop glass within. This behavior is gradual at first, and hastens as the cone reaches its maximum operating temperature. The time interval from when a cone begins to deform until the tip of the cone reaches the shelf is typically 15-25 minutes. The interpretation of the location of the tip of the cone along the bending arc can be done in a couple of ways. One method of interpretation is to correlate the position of the tip to the numbers on a clock face. Initially, the cone is in the 1 o'clock position and continues to deform until the tip is in contact with a shelf, the 6 o'clock position. A more precise method of interpretation is to use the Orton measuring template. The template measures the angle of deformation along a protracted scale numbered from 0 to 90°. The endpoint temperature for a cone is considered to be when the tip is measured with a 90° bend, or in the 5 o'clock position.

The difference in temperature between cones in the 90° (or 5 o'clock) position to one where the tip is touching the shelf is typically only a few degrees and is considered insignificant.

Temperatures shown on the